


Art. 160.1065



**Art. 160.1065**

| Part. No | Art.-Nr.       | Beschreibung       | Description        | Menge Qty. |
|----------|----------------|--------------------|--------------------|------------|
| 1-1      | 160.1065-R001P | Rahmen             | Frame              | 1          |
| 1-2      | 160.1065-R002P | Vordere Rolle      | Front Wheel        | 2          |
| 1-3      | 160.1065-R003P | Unterlegscheibe    | Washer             | 2          |
| 1-4      | 160.1065-R004P | Sicherungsring     | Snap Ring          | 2          |
| 1-5      | 160.1065-R005P | Schmiernippel      | Grease Fitting     | 3          |
| 1-6      | 160.1065-R006P | Verbindungsstrebe  | Rod Link           | 2          |
| 1-7      | 160.1065-R007P | Bolzen             | Bolt               | 2          |
| 1-8      | 160.1065-R008P | Aufnahmeteller     | Saddle             | 1          |
| 1-9      | 160.1065-R009P | Unterlegscheibe    | Lock Washer        | 2          |
| 1-10     | 160.1065-R010P | Mutter             | Nut                | 2          |
| 1-11     | 160.1065-R011P | Feder              | Spring             | 1          |
| 1-12     | 160.1065-R012P | Schraube M10x25    | Bolt M10x25        | 2          |
| 1-13     | 160.1065-R013P | Schraube M10x16    | Bolt M10x16        | 1          |
| 1-14     | 160.1065-R014P | Sicherungsring     | Snap Ring          | 2          |
| 1-15     | 160.1065-R015P | Bolzen             | Shaft              | 1          |
| 1-16     | 160.1065-R016P | Lenkrolle          | Rear Wheel         | 2          |
| 1-17     | 160.1065-R017P | Mutter             | Nut                | 2          |
| 1-18     | 160.1065-R018P | Sicherungsring     | Snap Ring          | 2          |
| 1-19     | 160.1065-R019P | Bolzen             | Shaft              | 1          |
| 1-20     | 160.1065-R020P | Unterlegscheibe    | Washer             | 1          |
| 1-21     | 160.1065-R021P | Bolzen             | Pin                | 1          |
| 1-22     | 160.1065-R022P | Verbindungsstange  | Connection Bar     | 1          |
| 1-23     | 160.1065-R023P | Feder              | Spring             |            |
| 1-24     | 160.1065-R024P | Sicherungsring     | Snap Ring          | 2          |
| 1-25     | 160.1065-R025P | Bolzen             | Shaft              | 1          |
| 1-26     | 160.1065-R026P | Abdeckung          | Cover Board        | 1          |
| 1-27     | 160.1065-R027P | Unterlegscheibe    | Lock Washer        | 2          |
| 1-28     | 160.1065-R028P | Sicherungsring     | Snap Ring          | 2          |
| 2-1      | 160.1065-R029P | Sicherungsring     | Snap Ring          | 2          |
| 2-2      | 160.1065-R030P | Unterlegscheibe    | Washer             | 1          |
| 2-3      | 160.1065-R031P | O-Ring             | O-Ring             | 1          |
| 2-4      | 160.1065-R032P | Hubkolben          | Piston Rod         | 1          |
| 2-5      | 160.1065-R033P | Kolbenring         | Piston Ring        | 1          |
| 2-6      | 160.1065-R034P | Dichtung           | Sealing Washer     |            |
| 2-7      | 160.1065-R035P | O-Ring             | O-Ring             | 1          |
| 2-8      | 160.1065-R036P | O-Ring-Halterung   | O-Ring Retainer    | 1          |
| 2-9      | 160.1065-R037P | Sicherungsring     | Snap Ring          | 1          |
| 2-10     | 160.1065-R038P | Zylinder           | Oil Cylinder Ass'Y | 1          |
| 2-11     | 160.1065-R039P | Öl Einfüllschraube | Oil Filler Plug    | 1          |
| 2-12     | 160.1065-R040P | Bolzen             | Pin                | 2          |

| Part. No | Art.-Nr.       | Beschreibung                    | Description           | Menge Qty. |
|----------|----------------|---------------------------------|-----------------------|------------|
| 2-13     | 160.1065-R041P | Stahlkugel 6mm                  | Steel Ball Ø6         | 1          |
| 2-14     | 160.1065-R042P | Stahlkugel 9mm                  | Steel Ball Ø9         | 1          |
| 2-15     | 160.1065-R043P | Feder                           | Spring                | 1          |
| 2-16     | 160.1065-R044P | Kupferdichtung                  | Copper Washer         | 1          |
| 2-17     | 160.1065-R045P | Schraube M12x20                 | Bolt M12x20           | 1          |
| 2-18     | 160.1065-R046P | Stahlkugel                      | Steel Ball            | 1          |
| 2-19     | 160.1065-R047P | Ventilsitz                      | Valve Seat            | 1          |
| 2-20     | 160.1065-R048P | Feder                           | Spring                | 1          |
| 2-21     | 160.1065-R049P | Schraube                        | Screw                 | 1          |
| 2-22     | 160.1065-R050P | O-Ring                          | O-Ring                | 1          |
| 2-23     | 160.1065-R051P | Sicherheitsventilschraube       | Safety Valve Screw    | 1          |
| 2-24     | 160.1065-R052P | Dichtung                        | Seals                 | 1          |
| 2-25     | 160.1065-R053P | Bolzen                          | Pin                   | 1          |
| 2-26     | 160.1065-R054P | Gestänge für Ablassventil       | Release Valve Rod     | 1          |
| 2-27     | 160.1065-R055P | Pumpzylinder                    | Cylinder Pump Plunger | 1          |
| 2-28     | 160.1065-R056P | Bolzen                          | Pin                   | 1          |
| 2-29     | 160.1065-R057P | O-Ring                          | O-Ring                | 1          |
| 2-30     | 160.1065-R058P | Nylonring                       | Nylong Gasket         | 2          |
| 3-1      | 160.1065-R059P | Lenkstangenaufnahme             | Handle Socket         | 1          |
| 3-2      | 160.1065-R060P | Fusspedal                       | Pedal                 | 1          |
| 3-3      | 160.1065-R061P | Mutter M10                      | Nut M10               | 1          |
| 3-4      | 160.1065-R062P | Unterlegscheibe                 | Washer                | 1          |
| 3-5      | 160.1065-R063P | Schraube M10x35                 | Bolt M10x35           | 1          |
| 3-6      | 160.1065-R064P | Handgriff                       | Handle                | 1          |
| 3-7      | 160.1065-R065P | Schaumstoffschutz für Lenkstan- | Handle Sleeve         | 2          |
| 3-8      | 160.1065-R066P | Drehknauf                       | Knob                  | 1          |
| 3-9      | 160.1065-R067P | Bolzen                          | Pin                   | 1          |
| 3-10     | 160.1065-R068P | Arretierungsstange              | Control Rod           | 1          |
| 3-11     | 160.1065-R069P | Feder                           | Spring                | 1          |
| 3-12     | 160.1065-R070P | Unterlegscheibe                 | Washer                | 2          |
| 3-13     | 160.1065-R071P | Schraube                        | Screw                 | 2          |
| 3-14     | 160.1065-R072P | Arretierungsbolzen              | Rod Joint             | 1          |
| 3-15     | 160.1065-R073P | Feder                           | Spring                | 1          |
| 3-16     | 160.1065-R074P | Unteres Ablassgestänge          | Universal Joint Ass'Y | 1          |
| 3-17     | 160.1065-R075P | Oberes Ablassgestänge           | Convey Rod            | 1          |
| 3-18     | 160.1065-R076P | Unterlegscheibe                 | Washer                | 1          |
| 3-19     | 160.1065-R077P | Bolzen                          | Pin                   | 2          |
| 3-20     | 160.1065-R078P | Bolzen                          | Pin                   | 1          |
| 3-21     | 160.1065-R079P | Unterlegscheibe                 | Washer                | 1          |